

# DKTV Kundecenter

Vidensbase > Router / Netværksboks > Router > D-Link > D-Link - Ændring af funktion (bridge-/routermode)

## D-Link - Ændring af funktion (bridge-/routermode)

- 2018-06-01 - D-Link

For at kunne ændre denne funktion forudsætter det, at du er logget ind i routeren.

[Vejledning kan findes her](#)

Ændring af funktion (bridge/router mode)

1. Log ind i routeren - se ovenstående
2. Vælg "Settings"
3. Klik på "Internet"
4. I feltet "Device mode" ændres routerens funktion fra "Router mode" til "Bridge mode" eller omvendt.
5. Klik på "Save"

The screenshot shows the D-Link web interface for a DIR-880L router. The top navigation bar includes 'Home', 'Settings', 'Features', and 'Management'. The 'Settings' menu is open, showing options like 'Wizard', 'Internet', 'Wireless', 'Network', 'SharePort', and 'mydlink'. The 'Internet' page is active, displaying a globe icon and instructions for configuring internet connections. Below the instructions, there are two dropdown menus: 'Device Mode' set to 'Router Mode' and 'My Internet Connection is:' set to 'Dynamic IP (DHCP)'. A 'Save' button is located at the bottom right of the settings area. A link for 'Advanced Settings...' is also visible.

Relateret indhold

- [D-link DIR-842](#)
- [D-link DIR-859](#)
- [D-link DIR-878](#)