

DKTV Kundecenter

Vidensbase > Router / Netværksboks > Router > D-Link > D-Link - Ændring af funktion (bridge-/routermode)

D-Link - Ændring af funktion (bridge-/routermode)


- 2018-06-01 - D-Link

For at kunne ændre denne funktion forudsætter det, at du er logget ind i routeren.

[Vejledning kan findes her](#)

Ændring af funktion (bridge/router mode)

1. Log ind i routeren - se ovenstående
2. Vælg "Settings"
3. Klik på "Internet"
4. I feltet "Device mode" ændres routerens funktion fra "Router mode" til "Bridge mode" eller omvendt.
5. Klik på "Save"



The screenshot shows the D-Link router's web interface. At the top, there is a navigation bar with 'Home', 'Settings', 'Features', and 'Management'. The 'Settings' menu is open, showing options like 'Wizard', 'Internet', 'Wireless', 'Network', 'SharePort', and 'mydlink'. The 'Internet' page is active, displaying a globe icon and instructions for configuring the Internet connection. Below the instructions, there are two dropdown menus: 'Device Mode' set to 'Router Mode' and 'My Internet Connection is' set to 'Dynamic IP (DHCP)'. A 'Save' button is located at the bottom right of the page. The breadcrumb 'Settings >> Internet' is visible in the top left of the content area.

Relateret indhold

- [D-link DIR-842](#)
- [D-link DIR-859](#)
- [D-link DIR-878](#)