

DKTV Kundecenter

Knowledgebase > Router / Netværksboks > Router > D-Link > D-Link - Ændring af funktion (bridge-/routermode)

D-Link - Ændring af funktion (bridge-/routermode)

- 2018-06-01 - D-Link

For at kunne ændre denne funktion forudsætter det, at du er logget ind i routeren.

[Vejledning kan findes her](#)

Ændring af funktion (bridge/router mode)

1. Log ind i routeren - se ovenstående
2. Vælg "Settings"
3. Klik på "Internet"
4. I feltet "Device mode" ændres routerens funktion fra "Router mode" til "Bridge mode" eller omvendt.
5. Klik på "Save"

The screenshot displays the D-Link router's web interface. At the top, the D-Link logo and model information (DIR-880L HW: A1 FW: 1.05VWW) are shown. The navigation menu includes Home, Settings, Features, and Management. The main content area is titled 'Internet' and contains instructions for configuring the Internet connection. A dropdown menu is open over the 'Device Mode' field, showing options: Wizard, Internet (highlighted), Wireless, Network, SharePort, and mydlink. Below the dropdown, the 'Device Mode' is currently set to 'Router Mode'. The 'My Internet Connection is:' field is set to 'Dynamic IP (DHCP)'. A 'Save' button is visible on the right side of the page. The breadcrumb trail shows 'Settings >> Internet'.

Related Content

- [D-link DIR-842](#)
- [D-link DIR-859](#)
- [D-link DIR-878](#)